

GENERAL NOTES:

- 1. This layout represents traffic controls required for:
 - (a) Work which does not interfere with traffic but does result in workers and equipment operating within 4 meters of the edge of the traveled way.
 - (b) Identifying areas where roadside work has been started but remains incomplete within 9 meters of the edge of the traveled way, except when no work or physical obstruction is present.
- A work area shall be established on one side of the road way only and there shall be no parking on the opposite shoulder within 150 meters of the work area.
- Speed Limit refers to the legally established speed limit in miles per hour before construction.
- 4. Where construction creates a shoulder dropoff or the shoulder area is tilled to a depth of 50 millimeters, a "Shoulder Dropoff" sign will follow the "Road Work Ahead" sign. When seedbed preparation on the shoulder creates such conditions, Type I barricades shall be required. Individual Type I barricades may be omitted during working hours in areas where placement interferes with the work.

 A "Road Work Ahead" sign shall be placed at each public road intersecting the project within the work area. In lieu of this sign, a "Shoulder Drop-off" sign shall be used when note 4 applies.

All dimensions given in millimeters unless noted.



OF THE TRAVELED WAY

- b Type II Barricade (To Be Weighted)

Type I Barricade (To Be Weighted)

Work Area

LEGEND

Traffic Sign